



Rinnai

SERVICE MANUAL

ULTIMA II - REH311FT

FLUED HEATER





The Australian
Gas Association

All Rinnai products are certified by the Australian Gas Association as compliant to relevant Australian Standards.



Quality
ISO 9001
SAI GLOBAL

Rinnai Australia Head Office is certified as complying with ISO 9001 by SAI Global.



Quality
Endorsed
Company

ISO 9001 Reg 415

Rinnai New Zealand has been certified to ISO 9001 Quality Assurance by Telarc.



All Rinnai products carry the “C Tick” symbol. This signifies compliance with the Electromagnetic Compatibility (EMC) requirements of the Australian Communications Authority (ACA) which aim to minimise electromagnetic interference.

Rinnai Australia Supplier Code N10378.

© Copyright Rinnai Australia Pty Ltd
A.B.N. 005 138 769 All rights reserved
Produced by Technical Services Department
2011



WARNING



No portion or part of this manual may be copied without prior permission from Rinnai Australia. Rinnai Australia takes no responsibility for the accuracy or otherwise of information contained in this manual, and reserves the right to make modifications and change specifications without notice.

Failure to comply with these instructions may result in serious personal injury or damage to the appliance.

ALL WIRING INSIDE THIS APPLIANCE MAY BE AT 240 VOLTS POTENTIAL

ALL SERVICE WORK MUST BE CARRIED OUT BY AN AUTHORISED PERSON.

DO NOT TEST FOR GAS ESCAPES WITH AN OPEN FLAME

This manual has been compiled by Rinnai Australia Technical Services Department. While many individuals have contributed to this publication, it will be successful only if you - the reader and customer - find it useful. We would like to extend an invitation to users of this manual to make contact with us, as your feedback and suggestions are valuable resources for us to include as improvements. Rinnai are constantly working toward supplying improved appliances as well as information, and specifications may be subject to alteration at any time.

*SM REH311FT Ultima
Issue P404*

Table of Contents

| | |
|--|----|
| 1. Introduction | 1 |
| 2. Specifications | 2 |
| 3. Dimensions | 3 |
| 4. Installation General | 4 |
| 5. Inbuilt Installation, Masonry Fire Place | 5 |
| 6. Console Installation, Cavity Twin Skin Flue | 8 |
| 7. Console Installation, Masonry Fire Places | 11 |
| 8. Operation Flow Chart | 14 |
| 9. Cut - Away Diagram | 15 |
| 10. Main Componentry | 16 |
| 11. Fault Finding Procedure | 19 |
| 12. Diagnostic Points | 20 |
| 13. Wiring Diagram | 21 |
| 14. Block Diagram | 22 |
| 15. Time Charts | 23 |
| 16. Gas Conversion / Gas Pressure Setting | 26 |
| 17. Dismantling for Service | 27 |
| 18. Parts List | 31 |
| 19. Exploded Diagrams | 36 |

Glossary of Terms and Symbols

This glossary of terms and symbols is provided to assist you in understanding some of the language used throughout this manual.

| | | |
|-------------|---|---|
| dB(A) | - | sound pressure level in decibels, “A” range |
| DC | - | direct current |
| AC | - | alternating current |
| Hz | - | Hertz |
| IC | - | integrated circuit |
| kcal/h | - | kilocalorie per hour |
| kPa | - | kilopascals |
| LED | - | light emitting diode |
| mA | - | milliamps |
| MJ/h | - | megajoule per hour |
| mm | - | millimetres |
| OHS | - | overheat switch |
| PCB | - | printed circuit board |
| CPU | - | central processing unit |
| POT | - | potentiometer |
| rpm | - | revolutions per minute |
| SV | - | solenoid valve |
| ø | - | diameter |
| Δ °C | - | temperature rise above ambient |
| POV | - | modulating valve |
| TH | - | thermistor |

1. Introduction

The Rinnai REH 311 ULTIMA II Flued Space Heater consists of a glass fronted combustion chamber with ribbon type gas burner and ceramic radiants. The 30 MJ/h gas heater is fitted with combustion and convection fans and includes over heat protection, flue blockage detection and flame supervision for safety. This unit also consists of a modulating gas valve and electronic temperature control.

Features

- 30 MJ/h fan assisted, radiant convection space heater.
- Top mounted control for easy operation.
- All Rinnai safety features including overheat/flame failure protection.
- Large capacity fan to circulate warm air effectively.
- Electronic automatic ignition system.
- Fan filter to protect the fan against dust and lint.


2. Specifications

| | | | | | |
|--|------------|--|--|----------------------|--|
| Model Number | | REH-311FTB | | REH-311FTC | |
| Model Identification | | Ultima II- Inbuilt | | Ultima II - Console | |
| Name of appliance | | Inbuilt Flued Space Heater | | Console Flued Heater | |
| Average Efficiency Rating | | 80% | | 80% | |
| Electrical Consumption (max). Watts | | 80 Watts | | 80 Watts | |
| Dimensions (Fireplace) Min.* (mm) | Width | 710 minimum | | N/A | |
| | Depth | 330 minimum | | | |
| | Height | 605 minimum | | | |
| Dimensions (Fireplace) Max. (mm) | Width | 710 maximum | | | |
| | Depth | 330 maximum | | | |
| | Height | 650 | | | |
| Dimensions (mm) (Enclosure inside Fireplace) | Width | 700 | | 13 | |
| | Depth | 253 | | | |
| | Height | 635 | | | |
| Dimensions (mm) (Outside Fireplace) | Width | 910 | | 910 | |
| | Depth | 235 | | 370 | |
| | Height | 650 | | 650 | |
| Colours: | | Beige / Gunmetal | | | |
| Weight | Kg | 48 | | | |
| Heating Output Min. * / Max. | (kW) | 7.3 | | | |
| | | 3.3 | | | |
| Gas Consumption (MJ's) | (Max). | 30 | | | |
| | (Min). | 15 | | | |
| Clearances (mm) | | Not to be installed into a mock fireplace | | | |
| | Sideways | 150 | | | |
| | Infront | 1000 | | | |
| | Above | 150 | | | |
| | Behind | 150 | | | |
| Burner | | Stainless Steel Bunsen Ribbon burner | | | |
| Noise level range | dB (A) | High: 51 | | Low: 44 | |
| Gas Input (MJ/h) NG | High | 30 | | 30 | |
| | Low | 15 | | 15 | |
| LPG | High | 30 | | 30 | |
| | Low | 15 | | 15 | |
| Connections | Gas | 1/2 inch (15mm) Copper flare connection | | | |
| | Electrical | 240 V power point (10 Amp GPO) | | | |
| Room Temperature control | | Thermostat control | | | |
| Controls | | Slide heat control variable settings | | | |
| Gas Control | | Electronic | | | |
| Fan Switch | | Boost - Normal | | | |
| Ignition System | | One touch electronic | | | |
| Timer | | 12 hour slide delay | | | |
| Safety devices | | Automatic Fan delay switch Flame Failure Device Over-heat switch | | | |
| Accessories | | Surround:75 mm or 100 mm fireplace | | | |
| Flueing | | 10' x 2' flueing is supplied from plumbing outlets only (not supplied by Rinnai) | | | |

* minimum values are approximate only

3. Dimensions

Note: All dimensions are in millimetres



| Legend | | | | | | | | | | | |
|---------|--------|---|--------|---|----------|---|--------|---|--------|---|------------------------|
| CONSOLE | | | | | | | | | | | |
| A | 910 mm | C | 265 mm | E | 13.6 mm | G | 600 mm | I | 114 mm | K | Total Installed Depth* |
| B | 653 mm | D | 24 mm | F | 93 mm | H | 280 mm | J | 393 mm | | 404 mm |
| INBUILT | | | | | | | | | | | |
| A | 910 mm | C | 140 mm | E | 138.6 mm | G | 600 mm | I | 114 mm | K | Total Installed Depth* |
| B | 653 mm | D | 24 mm | F | 93 mm | H | 280 mm | J | 393 mm | | 164 mm |

*The total installation depth includes the Dress Guard and where applicable the rear cover kit.

4. Installation General




The following pages contain information relating to Installation and Service. Failure to comply with these instructions could result in a fire or explosion, which could cause serious injury, death or property damage.

Improper installation, adjustments, service or maintenance can cause serious injury, death or property damage. Such work must be performed by an authorised person.



- The appliance must be installed in accordance with the local gas and electrical authority regulations.
- This appliance must not be installed where curtains or other combustible materials could come into contact with it. In some cases curtains may need restraining.
- This appliance discharges a large volume of warm air at low level to provided even heat distribution.
- Some nylon carpets contain dyes which may be affected by the warm air flow.
- Heat emanating from the front of this appliance may over time affect the appearance of some materials used for flooring such as carpet, vinyl, cork or timber. This effect may be amplified if the air in the room contains cooking vapours or cigarette smoke. To avoid this possibility, it is recommended that a mat be placed in front of the appliance, extending at least 750 mm in front of it.
- If the supply cord is damaged or requires replacing, it must be replaced by the manufacturer or the manufacturer's agent or similarly qualified person in order to avoid a hazard.



The above diagram shows the clearances required around this heater whilst in operation

1. MAIN POINTS GOVERNING HEATER LOCATION

- Suitable Installation Type
 - Ultima II Inbuilt: Suitable for masonry fireplace installations **ONLY!**
 - Ultima II Console: Suitable for a masonry fireplace installation, or against a wall using a twin skin flue in the wall cavity.



Ultima II Console and Inbuilt models are NOT SUITABLE for 'built in' installations other than a masonry fireplace as described in this manual. They are not suitable for installation into non masonry or 'false' fireplaces, bookcases or shelves.

- Flue connection and cowl to comply with AS/NZS 5601.
- Warm air distribution.
- Ensure that the area in which the appliance is installed has adequate fixed ventilation, this fixed ventilation must be provided in accordance with AS/NZS 5601.

2. UNPACKING THE APPLIANCE

- Undo straps.
- Lift carton off heater, never lift heater out of carton by top louvres.
- Check for damage. If the heater is damaged, contact your supplier for advice.
- Before installing this appliance, check it is labelled for the correct gas type (see label on rear of heater). Refer to local gas authority for confirmation of gas type if you are in doubt.
- For the Ultima II Inbuilt model only, before installation, remove & discard the triangular packing brackets from rear top of the front casing.


The following additional items should be included in the carton:

- | | |
|---------------------------|--|
| • Radiants (2 packs of 3) | • Foam sealing strip (Inbuilt only) |
| • Flue spigot and screws | • Rear Cover Kit and screws with wall brackets (Console only). |

3. ELECTRICAL SUPPLY

The heater has a power cord with a three pin plug supplied.


Rinnai recommends that the heater be plugged into a 240V, 10A earthed power point. The power point must be a minimum of 300mm to the side of the heater (it must not be above the heater).



Alternatively - heater can be direct wired if the power supply is to be concealed. Consult a qualified electrician if direct wiring is required as it must comply to AS/NZS 5601 and AS/NZS 3000.



5. Inbuilt Installation, Masonry Fire Place

1. CHECK DIMENSIONS OF FIREPLACE

| Masonry Fireplace Dimensions | | |  |
|------------------------------|--------|----------------------------------|---|
| Ⓜ | Width | 710 mm minimum 805 mm maximum | |
| ⓗ | Height | 605 mm minimum 635 mm maximum | |
| ⓓ | Depth | 330 mm minimum | |


2. CHECK FLUEWAY

- Remove damper plate/baffle - Any damper plate or baffle which has been installed in the chimney shall be removed.
- Check flueway is clear of obstructions.
- Check dimensions of fireplace and if necessary remove any protruding brickwork to give 75 mm minimum clearance from flue spigot.
- Provide a firm, flat and sealed base for heater. A rough base may cause rattles and affect performance.
- Check that there are no unwanted holes or openings in fireplace. If so these must be sealed.
- The chimney must be confirmed free of soot and creosote that may have built up if previously used for a solid fuel fire. Before installing the heater, inspect the chimney, flue piping and/or solid fuel burning fire place and remove any combustible materials.
- A gas appliance must not be connected to a chimney flue serving a separate solid-fuel burning appliance.
- Peel protective backing off the foam strips supplied with the heater.
- Attach strips supplied with the heater. The strip is intended to form a seal between the heater and fireplace. If an adequate seal cannot be formed with this strip another means of sealing must be used (e.g. fibreglass batts), between the fireplace and the heater body.



3. FIT FLUE SPIGOT


- The flue spigot is packed separately in the carton.
- It must be fitted to all models, inbuilt and console.



4. GAS INLET UNION

- For ease of connection a combined gas inlet union/copper elbow is provided with every heater. It is situated at the bottom right hand side below the control.

Union connection to heater




5. REMOVE GAS INLET UNION FROM HEATER

- The inlet union/elbow should be fitted to the end of the copper supply tube before installing the heater in the fireplace opening.


For access to union:

- Remove bottom louvre panel, 2 screws in the lower right and left hand corners of louvres.
- Remove upper front panel, 2 screws at the bottom right and left hand edges of the panel.
- Lift panel to disengage top and remove from heater.
- Do not lift the panel by the dress guard or top louvres.
- Remove union.
- Ensure that removal and replacement of the bottom panel is not obstructed by carpet etc.




6. GAS CONNECTION POSITION

- Drawing is viewed from rear of heater.
- Actual connection is on right hand side when viewed from front.
- Dimensions are to the centre of the flare fitting on the inlet elbow/union. Flare fitting suits 15 mm copper tube.



7. RUN GAS SUPPLY

- Refer to AS/NZS 5601AS/NZS 5601 or other approved pipe sizing chart if in doubt about size of gas line.
- Copper supply should be run leaving a flare connection the position shown.
- Connect the union/elbow fitting to the copper supply with the union nut facing upwards.
- Purge supply of air and swarf.
- All foreign materials such as filings must be purged from the gas supply, as they could cause the gas valve to malfunction.




Don't forget to put flare nut on tube before flaring.



Gas pipe sizing must consider the gas input to this appliance as well as all other gas appliances in the premises. The gas meter and regulator must be specified for the total gas rate. Suitable sizing chart such as the one in AS/NZS 5601AS/NZS 5601 should be used.


8. INSTALL THE HEATER

- Feed the copper tube through the supply access opening.
- Connect and tighten gas supply union.
- Secure heater to fireplace, there are pre-drilled holes in the heater flanges.
- Drill additional holes if the existing ones are not in suitable positions.




9. INSTALL RADIANTS

- Remove glass panel, install radiants as shown.
- Replace glass panel.




10. CHECK FOR GAS ESCAPES

- Use a manometer or soapy water.
- **DO NOT USE A NAKED FLAME.**




11. CLOSE GAS SUPPLY COVER

- This seals the heater from the chimney and prevents chimney draughts affecting the performance of the heater, as well as preventing the entry of debris from the chimney.



12. INSTALL COWL

- A cowl certified for gas appliances must be installed on all chimneys.
- Clearances to conform with AS/NZS 5601.
The minimum clearance between top of chimney and the lowest opening in the flue cowl is 200 mm as shown.
- Size: 100 mm.



13. TEST APPLIANCE

- Refer to Commissioning section of manual.


14. INSTRUCT CUSTOMER

- Instruct customer on operation and servicing of the appliance.
- Remind customer of dress guard requirements.

6. Console Installation, Cavity Twin Skin Flue


1. GENERAL

- Depth of cavity wall must be at least 75 mm.
- Select position of heater and locate studs. There must be a minimum distance of 345 mm and a maximum distance of 550 mm between studs.
- Ensure ceiling and roof structure will not obstruct flue.



2. CUT OPENING IN WALL

- The wall box measures 330 mm x 100 mm but the opening required is 335 mm x 160 mm. This is to allow for ventilation around the wall box.
- Failure to cut the correct sized hole may lead to excessively high wall temperatures.



Gas supply position
Ⓐ is measurement
to end of flare

3. RUN GAS SUPPLY


- The gas supply should be run before installing the heater. The easiest way is to run the supply, leaving the end of the copper flare as shown in the diagrams, then attach the elbow / union to the copper supply when the heater is installed.
- Refer to an approved pipe sizing chart such as the one in AS/NZS 5601 'Gas Installations' if in doubt about size of supply pipe.

4. CUT AWAY THE TOP PLATE AND ANY NOGGINS BETWEEN STUDS

Fit flue housing into prepared opening:

- Tabs should be fitted tightly against the plaster board.
- Drill through flanges at stud centres and fix to wall with 4 screws.
- The housing must be secured to the studs to allow the outlet to protrude back into the cavity, giving the twin skin flue a minimum clearance from plaster board of 10 mm, excluding spacers (covers).

Housing fitted to opening



5. LOWER TWIN SKIN FLUE DOWN CAVITY


- Straighten tabs at bottom of twin skin flue assembly and lower down wall cavity to housing.
- Insert tabs in slots in housing then bend tabs to secure flue to housing.

6. INSTALL FLUE SUPPORT

- Drop top plate flue support over top of flue, position centrally in space between studs and secure support in position.


7. FIT SEALING PLATE

- If flue protrudes more than 65 mm above top plate, adaptor supports must be screwed to the flue, and positioned so that when the sealing plate is fitted it is 50 mm from the top of the flue.



8. FIT RECTANGULAR TO ROUND ADAPTOR


- Fit adaptor to top of twin skin.
- Fit 100 mm flue and approved cowl.
- Flue termination above the roof must comply with AS/NZS 5601.
- Locate the longer end inside the aluminium liner of twin skin.
- Position elbow into housing.
- The flue must be supported independently of the heater to comply with AS/NZS 5601.
- Attach loosely to housing with screw provided.
- Measure distance from floor to flue outlet.
- Adjust elbow to these dimensions, tighten screw.
- Fit right and left hand rear spacers (covers) to Heater.
- Place top spacer (cover) in position temporarily for wall marking.
- Remove front cover and inlet union.



9. GAS INLET UNION

- For ease of connection a combined gas inlet union/copper elbow is provided with every heater. It is situated at the bottom right hand side below the control.

Union connection to heater




10. REMOVE GAS INLET UNION FROM HEATER

- The inlet union/elbow should be fitted to the end of the copper supply tube fore installing the heater in the fireplace opening.


For access to union:

- Remove bottom louvre panel, 2 screws in the lower right and left hand corners of louvres.
- Remove upper front panel, 2 screws at the bottom right and left hand edges of the panel.
- Lift panel to disengage top and remove from heater.
- Do not lift the panel by the dress guard or top louvres.
- Remove union.
- Ensure that removal and replacement of the bottom panel is not obstructed by carpet etc.




11. GAS CONNECTION POSITION

- Drawing is viewed from rear of heater.
- Actual connection is on right hand side when viewed from front.
- Dimensions are to the centre of the flare fitting on the inlet elbow/union. Flare fitting suits 15 mm copper tube.




12. INSTALL HEATER

- Mark position of top of spacer (cover) on wall.
- Fit wall clips.
- Feed the copper tube through the supply access opening.
- Install heater, ensure spigot is correctly engaged into elbow.
- Replace top spacer (cover), clipping the spacer (cover) into the wall brackets at the same time as attaching it to the heater.
- Secure top spacer (cover) with the four screws provided.
- The heater is now secured to the wall.




13. INSTALL RADIANTS

- Remove glass panel, install radiants as shown.
- Replace glass panel.




14. CHECK FOR GAS ESCAPES

- Use a manometer or soapy water.
- **DO NOT USE A NAKED FLAME.**



15. CLOSE GAS SUPPLY COVER

- This seals the heater from the chimney and prevents chimney draughts affecting the performance of the heater, as well as preventing the entry of debris from the chimney.



16. TEST APPLIANCE

- Refer to Commissioning section of manual.


17. INSTRUCT CUSTOMER

- Instruct customer on operation and servicing of the appliance.
- Remind customer of dress guard requirements.

7. Console Installation, Masonry Fire Places


1. GENERAL

- In this type of installation the fireplace is closed off with fireproof material. The heater is placed against the fireproof material and a hole is cut for penetration of the flue spigot into the fireplace.
- The flue spigot must have an extension added to extend beyond overhead brickwork. The extension must be constructed so that it prevents falling debris entering the flue spigot. Cutting the end of the spigot at a 45 degree angle facing downwards will achieve this.
- The spigot extension must not be extended so far into the chimney as to cause an obstruction to the discharge of flue gases. The minimum clearance from the end of the spigot extension to any obstruction is 75 mm.
- DO NOT install heater below a wooden shelf.




2. PREPARE FIREPLACE

- Remove any damper plates or baffles.
- Check flueway is clear of obstructions.
- Check fireplace dimensions and, if necessary, remove any brickwork to provide 75mm clearance between the end of the spigot extension and any obstruction.
- Check there are no unwanted holes or openings in the fireplace. If so these must be sealed, so that the fireplace is in a sound condition.
- The chimney shall be confirmed free of soot and creosote that may have built up if previously used for a solid fuel fire. Remove combustible materials or substances before installing the heater.
- A gas appliance must not be connected to a chimney serving a separate solid fuel burning appliance.
- Provide a firm, flat and sealed base for the heater. A rough or uneven base may cause rattles and affect performance.
- Close off the fireplace with a fireproof material and cut hole for flue spigot as shown.



3. INSTALL COWL


- A cowl certified for gas appliances must be installed on all chimneys.
- Clearances to conform with AS/NZS 5601. The minimum clearance between top of chimney and the lowest opening in the flue cowl is 200 mm as shown.
- Size: 100 mm.



4. GAS INLET UNION

- For ease of connection a combined gas inlet union/ copper elbow is provided with every heater. It is situated at the bottom right hand side below the control.

Union connection to heater




5. REMOVE GAS INLET UNION FROM HEATER

- The inlet union/elbow should be fitted to the end of the copper supply tube before installing the heater in the fireplace opening.


For access to union:

- Remove bottom louvre panel, 2 screws in the lower right and left hand corners of louvres.
- Remove upper front panel, 2 screws at the bottom right and left hand edges of the panel.
- Lift panel to disengage top and remove from heater.
- Do not lift the panel by the dress guard or top louvres.
- Remove union.
- Ensure that removal and replacement of the bottom panel is not obstructed by carpet etc.




6. GAS CONNECTION POSITION

- Drawing is viewed from rear of heater.
- Actual connection is on right hand side when viewed from front.
- Dimensions are to the centre of the flare fitting on the inlet elbow/union. Flare fitting suits 15 mm copper tube.



7. RUN GAS SUPPLY

- Refer to AS/NZS 5601 or other approved pipe sizing chart if in doubt about size of gas line.
- Copper supply should be run leaving a flare connection the position shown.
- Connect the union/elbow fitting to the copper supply with the union nut facing upwards.
- Purge supply of air and swarf.
- All foreign materials such as filings must be purged from the gas supply, as they could cause the gas valve to malfunction.



Don't forget to put flare nut on tube before flaring.




Gas pipe sizing must consider the gas input to this appliance as well as all other gas appliances in the premises. The gas meter and regulator must be specified for the total gas rate. Suitable sizing chart such as the one in AS/NZS 5601 should be used.

8. INSTALL HEATER

- AS/NZS 5601 Fit right and left rear spacers (covers) to heater.
- Place top spacer (cover) in position temporarily for wall marking.
- Attach flue spigot extension to heater.
- Feed the copper tube through the supply access opening.
- Secure heater to the fireproof material using the clips in the top spacer (cover).
- Connect and tighten the gas supply.


9. INSTALL RADIANTS

- Remove glass panel, install radiants as shown.
- Replace glass panel.




10. CHECK FOR GAS ESCAPES

- Use a manometer or soapy water.
- **DO NOT USE A NAKED FLAME.**



11. CLOSE GAS SUPPLY COVER

- This seals the heater from the chimney and prevents chimney draughts affecting the performance of the heater, as well as preventing the entry of debris from the chimney.




12. TEST APPLIANCE

- Refer to Commissioning section of manual.

13. INSTRUCT CUSTOMER


- Instruct customer on operation and servicing of the appliance.
- Remind customer of dress guard requirements.

<RFH-311FT FLOW CHART>



9. Cut - Away Diagram

REH-311FTC



10. Main Componentry

Test Point Location

On the injector block in front of the burner.

Regulator

Spring loaded adjustable type, with inlet gas filter located after the brass elbow coupling.

Gas Control

Fully automatic Electronic controlled system. Rinnai gas control unit printed circuit board electronically controls one ON/OFF and two HI/LO gas solenoid valves.

ON/OFF Solenoid Valve Assembly - is a single solenoid valve assembly (SV1), 90 Vdc, with a approx. winding resistance of 1.5 Ohms.

HI/LO Solenoid Valve Assembly - a double solenoid valve assembly (SV2-bottom, SV3-top), 90 Vdc, winding resistance 1.7 Ohms approximately, with replaceable LP or NG by-pass restrictor screw.

Ignition

Automatic electronic ignition system without re-ignition supplying continuous spark direct to main burner.

On initial light-up, two ignition attempts are made before lockout occurs.

| | |
|----------------------|-----------------------|
| Ignition unit: | K105S, 100 Vdc, 11 kV |
| Spark electrode gap: | 3 mm \pm 1 mm |

Flame Safeguard

Electronic flame failure system, plugged into the gas control PCB (connector CN3). Flame current must be more than 1 μ A_{dc} or lockout will occur. (ON/OFF gas valve immediately shuts-off).

Ignition unit output to flame failure system is 3Vdc.

Burner

Pressed stainless steel ribbon burner with a single injector. Primary air is adjustable by rotating the graduated air-metering cover on the burner air/gas intake nozzle. Combustion air is filtered at the air intake. The ignition electrode and flame sensor rod are both mounted on the burner assembly.

Pilot Burner Assembly

The pilot burner assembly consists of the assembly mounting plate and pilot burner. Pilot injector orifice is located in the pilot/pilot gas pipe connection. Pilot injector has an integral filter screen. Gas flows to pilot whenever the left hand control push button is in the depressed position, provided that the thermo-electric safety shut off valve is open.

Radiants

Six ceramic box type radiants with 14 cross bars.

| | |
|-------------|----------------|
| Dimensions: | Length: 220 mm |
| | Width: 84 mm |
| | Depth: 56 mm |

Gas Supply Filter

Removable mesh type filter installed in the brass elbow coupling to regulator.

Overheat Switch

Mounted at the top of the flue extraction housing on the inside back panel of the unit. Normally closed, automatic reset-bi-metal type heat operated switch. Screw mounted, with push-on type terminals.

Opens at 120° C and closes at 100° C.

Fan Switch 1

Mounted at the bottom of the flue extraction housing on the inside back panel of the unit. Normally open, automatic reset, bi-metal type heat operated switch. Screw mounted, with push-on type terminals. Allows the convection fan to run after burner shut-down until unit cools. Opens at 70° C, and closes at 58° C.

Pressure Switch

Mounted at the top right hand corner inside the appliance. Normally open switch, closed by air pressure. Monitors the flue extraction chamber air pressure and shuts the unit down if the combustion fan fails. Screw mounted, with push-on type terminals.

Main On-Off Switch

On/Off push button type switch mounted on the control panel. Rated at 5A/40A 240 V. Screw mounted with soldered connections.

Fan Switch 2 (Normal - Boost)

Normal/Boost fan selector switch, push-button type mounted on the control panel. Rated at 5A/40A, 250V. Screw mounted with soldered connections.

Supply Fuse (240 V)

Mounted at the lower right hand corner, inside the unit. Three amp (3A) 3AG cartridge type fuse (standard type 30 mm x 6 mm dia). Accessed through the plastic grill on the right hand side panel.

Room Temperature Control

Electronic / Thermistor type thermostat.

Incorporates room temp. manual control on control panel. Negative temperature coefficient (NTC) type thermistor, senses room temperature. Mounted on the plastic grill on the right hand side of unit. Plugged into the main PCB at connector CN7. Typical resistance range 10 k - 100 k Ohms.

Slide Control resistor-room temperature.

Room temperature HI/LO slide control potentiometer, mounted beneath the control panel. Controls room temperature between 13 and 39°C (± 3°C). Resistance readings: **HI** - 0 Ohm - **LO** - 32 k Ohm.

Convection Fan

Tangential type blower 90 mm dia. x 380 mm long, direct coupled to the fan motor.

Induction type 4-pole, dual speed electric motor 100 V, 6W, with a 4 µF capacitor in the start/run circuit. Fan speed circuit includes the ceramic resistor (102 Ohm). Convection fan can run at three speeds:

- Normal / Boost or Low (low setting is automatically switched).
Fan speed (RPM) : **LOW**: 1020, **NORMAL**: 1155, **BOOST**: 1260.

Typical motor winding fan speed resistor values:

NORMAL - red (2), black (1) = 80 Ohm + 102 Ohm resistor.

BOOST - red (2), black (1) = 80 Ohm

LOW - red (2), white (1) = 226 Ohm

Start / run winding - orange, orange wires = 335 Ohm.

Start run capacitor

Capacitor type SH-CAP, 4 µF, F-M, 200 V.

Screw mounted with two push-on spade terminals. Capacitor is in series with the convection fan motor start windings (335 Ohm) for both starting and running.

Ceramic Resistor

Fan speed circuit component. White ceramic type 102 Ohm, 65 x 10 x 10 mm, screw mounted with two push-on spade terminals. Located at top right hand corner inside the unit.

Combustion Fan

Single speed 2350 RPM (hot), 100 V motor direct coupled to two fan rotors:

1. Flue chamber extraction fan (impeller wheel type) located inside the unit heat exchanger compartment.
2. Blade type cooling fan mounted in front of the motor on the outside of the unit rear casing panel.

Motor is screw mounted on four anti-vibration mounts and has a polarised two-pin plug type connector. Typical motor winding is 21 Ohm.

Printed Circuit Board (PCB)

Gas Control unit (main PCB). Has seven plug-in connectors identified as CN-1 to CN-7.

It computes the room temperature requirements set on the control panel against the current room temperature and delivers the heat / air output to satisfy those requirements.

Safety circuits monitor flame failure, power failure and combustion fan failure conditions and the unit will show down should a failure be detected. The PCB also supplies 90 V for the ignition unit and solenoid valves.

Main Transformer TR1

Primary power transformer 240 / 100 / 240 V. Located at the top right hand corner inside the cabinet, the larger of the two transformers.

Typical winding resistances are:

240 V winding - brown (1) and black (5) = 21 Ohm.

100 V winding - red (2) and black (6) = 6.7 Ohm.

240 V winding - orange (3) and orange (7) = 12.2 Ohm.

Small Transformer TR2

Power transformer 100 / 216 / 15 V. Located the at top right hand corner inside the cabinet, the smaller of the two transformers.

Typical winding resistances are:

100 V winding - black (2) and yellow (1) = 85 Ohm.

216 V winding - red (11) and red (12) = 1.5 Ohm.

150 V winding - white (13) and white (14) = 2.8 Ohm.

11. Fault Finding Procedure

| | Nature of fault | Fault code | Examination point | Diagnostic point | Values | Y/N | Action |
|---|--|------------|--|----------------------------|----------------|-----|--|
| 1 | Power failure | -:-- or 00 | Is there power to the power point? | Check power point? | AC 216-264VAC | Yes | Go to (2) |
| | | | | | | No | Check and restore power supply and press on/off button twice to re set heater |
| | | | Is there power to the appliance? | Check Power point and Lead | AC 216-264 VAC | Yes | Go to (2) |
| | | | | | | No | Check and repair / replace faulty plug or lead. Check 3A fuse replace if necessary |
| 2 | Combustion fan does not operate | 61 | Flue outlet | Visual | | Yes | Go to (3) |
| | | | | | | No | Check power to combustion fan |
| | Is power available to combustion fan | | Check power at connector to combustion fan at rear of heater | Connector | 240V | Yes | Check resistance across combustion fan motor windings Black – White 218.8Ω, Black – Red 249.1Ω, White – Red 31Ω |
| | | | | | 240V | No | Check connector on PC and wiring from PC to combustion fan connector at rear of heater. If no power faulty PCB. |
| 3 | No damage to plug and wiring from PCB to fan | 11 | Check plug and wiring from PCB to combustion fan | Visual | | Yes | Faulty PCB . Replace |
| | | | | | | No | Rectify damage. Restore power to Combustion fan |
| | No spark ignition | | | | | Yes | Go to (4) |
| | | | | | | No | Check flame sensor lead and probe for damage and replace if necessary |
| | Spark occurs but burner does not ignite | 53 | HT Lead and ceramic igniter/ Spark sensor lead | Visual | | Yes | Check spark igniter and lead. Check spark sensor and lead. Check gas supply. Check power to Solenoids, if ok check resistance across Solenoids 1 & 2 is 8.95kΩ, Resistance across modulating valve solenoid is 74Ω. Replace if necessary. |
| | | | | | | No | Go to (4) |
| 4 | Burner ignites but goes off after a while. | 12 | Check main burner | Visual | | Yes | Check if flame sensor rod is disconnected /damaged. repair/replace as necessary . |
| | | | | | | No | Go to (5) |
| 5 | Does Convection fan operate | 14 | | Visual | | Yes | Ok. Lighting up sequence complete. |
| | | | | | | No | Check resistance across OH sensor ~117kΩ Check power to fan. Check capacitor. Replace if faulty. Check fan motor windings. 0.935kΩ across windings. Red & White wires. Replace fan if no resistance. Check fusible link, if overheated one shot fusible link will shut gas supply to heater. |
| | Does heater shut off after operating for a while | 90 | Main burner off | Visual | | Yes | Check Flue for blockage, check flue gas temperature. Check Flue overheat thermistor. Resistance 16.3kΩ. Some earlier models required replacement of fan barrel. Check year of manufacture. |

SERVICE

Rinnai recommend that this appliance be serviced every 2 years.

If the power supply cord, gas supply hose or any other component of the heater is damaged, they must be replaced by Rinnai or a suitably qualified person.


Any service or repair work should only be carried out by an authorised person.

Rinnai Australia has service and spare parts departments.

Fault Finding Procedure

If you are unsure about the way your heater is operating, contact Rinnai Australia, or your local agent.


13. Wiring Diagram




| MARK | PARTS NAME |
|---------|---------------------------|
| SP | SPARKER |
| ER | ELECTRODE |
| POV | MODULATING SOLENOID VALVE |
| TF | THERMAL FUSE |
| FR | FLAME ROD |
| C | CAPACITOR |
| R | RESISTOR |
| SV1,2 | MAIN SOLENOID VALVE 1,2 |
| F | FUSE |
| FLUE.TH | FLUE THERMISTOR |
| OH.TH | OVER HEAT THERMISTOR |
| R.TH | ROOM THERMISTOR |

| CODE | COLOR |
|------|--------------|
| Bk | black |
| Bl | blue |
| G/Y | green/yellow |
| R | red |
| W | white |
| Y | yellow |
| Gy | gray |
| O | orange |

14. Block Diagram






























15. Time Charts



(CHART B: ABNORMAL OPERATION)

| | MIS-FIRE 11 FLASHES | SPARK CATCH MISTAKE 53 FLASHES | COMBUSTION FAN R.P.M. ABNORMAL (UP) 61 FLASHES |
|-------------------------------------|------------------------|-----------------------------------|--|
| OPERATION SWITCH | | | |
| OPERATION/ COMBUSTION LAMP (RED) | | | |
| COMBUSTION FAN | | | |
| IGNITER | | | |
| SPARK SENSER | | | |
| MODULATING VALVE | | | |
| SOLENOID VALVE (SV1, SV2) | | | |
| FLAME ROD (FLAME SENSER) | | | |
| CONVECTION FAN | | | |
| OVERHEAT THERMISTOR | | | |
| FLUE THERMISTOR | | | |
| BURNER COMBUSTION | | | |
| SET TEMPERATURE | | | |
| ROOM TEMPERATURE | | | |
| REMARKS | | | |

(CHART C:ABNORMAL OPERATION)

| | FLAME FAILURE 12 FLASHES | ABNORMAL TEMPERATURE 14 FLASHES | ABNORMAL TEMPERATURE 90 FLASHES |
|---|--|--|--|
| OPERATION SWITCH | | | |
| OPERATION/ COMBUSTION LAMP (GREEN) (RED) | | | |
| COMBUSTION FAN |  |  |  |
| IGNITER | | | |
| SPARK SENSER | | | |
| MODULATING VALVE |  |  |  |
| SOLENOID VALVE (SV1,SV2) |  |  |  |
| FLAME ROD (FLAME SENSER) |  |  |  |
| CONVECTION FAN |  |  |  |
| OVERHEAT THERMISTOR |  |  |  |
| FLUE THERMISTOR |  |  |  |
| BURNER COMBUSTION |  |  |  |
| SET TEMPERATURE | | | |
| ROOM TEMPERATURE | | | |
| REMARKS |  MAX 900" |  MAX 900" |  MAX 900" |

16. Gas Conversion / Gas Pressure Setting



Refer Seperate Rinnai document behind front cover of appliance.

17. Dismantling for Service



*240 volt potential exposure. Isolate the appliance and reconfirm with a neon screwdriver or multimeter.
Disconnect gas supply*

- | | | |
|----|---|----|
| 1. | To remove glass front of combustion chamber and access radiants | 28 |
| 2. | To remove Burner | 28 |
| 3. | To remove Convection Fan | 28 |
| 4. | To remove PCB | 28 |
| 5. | To remove Heat Exchanger | 30 |
| 6. | To remove Combustion Fan | 30 |
| 7. | Combustion fan assembly behind heat exchanger. | 30 |

Unless otherwise stated, re-assembly is the reverse of dismantling.






240 volt potential exposure. Isolate the appliance & reconfirm with a neon screwdriver or multimeter. Disconnect gas supply.


1) To remove glass front of combustion chamber and access radiants

1. Remove 10 screws as shown.




2) To remove Burner

1. Loosen screw from gas valve and remove burner pipe assembly.



2. Remove the 3 screws supporting the burner assembly including the screw from the gas valve. See above photo.
3. Remove 2 screws from bracket.



3) To remove Convection Fan

1. Isolate the 240 V power supply to the appliance.
2. Disconnect fan from electrical connector.
3. Disconnect 2 wires connecting fan to capacitor.
4. Remove 4 screws securing fan to appliance.




See following photos next page.






240 volt potential exposure. Isolate the appliance & reconfirm with a neon screwdriver or multimeter. Disconnect Gas Supply.

5. Disconnect fan from connector.
6. Disconnect 2 wires from capacitor.
7. Remove 2 screws from right hand side of fan.
8. Remove 2 screws from the left hand side of the fan.



4) To remove PCB

1. Isolate power to the appliance.
2. Remove all connectors and wiring from PCB.
3. Remove screw from bottom of PCB.
4. Carefully raise and remove PCB off the panel.
5. Raise PCB off hinge and remove.
6. Remove screw.






240 volt potential exposure. Isolate the appliance & reconfirm with a neon screwdriver or multimeter. Disconnect Gas Supply.


5) To remove Heat Exchanger

1. Remove burner assembly.
2. Undo 5 screws on the outside of heat exchanger.
3. Remove heat exchanger.
4. Undo 5 screws as indicated in photo.




6) To remove Combustion Fan

1. Isolate power supply to the appliance.
2. Remove burner assembly.
3. Remove heat exchanger. (See photo above).
4. Undo 5 screws as indicated in photo and release fan assembly from behind heat exchanger.
5. Disconnect fan from 2 connectors.



7) Combustion fan assembly behind heat exchanger

1. Remove 5 screws as shown on the above picture to release fan.
2. Disconnect 2 connectors to remove fan.



18. Parts List

Effective: 26/06/12
 Supersedes: 27/03/12
 V5

REH-311FTB-1S / REH-311FTB-1A / REH-311FTC-1S / REH-311FT

| | | | | INBUILT - G.SILVER | INBUILT - BEIGE | CONSOLE - G.SILVER | CONSOLE - BEIGE |
|-----|------------------------------|----------------|---------------|--------------------|-----------------|--------------------|-----------------|
| NO. | PART NAME | RA PART NUMBER | 11 DIGIT CODE | | | | |
| 001 | Panel Front | 90190634 | 019-3696000 | 1 | | 1 | |
| 001 | Panel Front | 90191636 | 019-3697000 | | 1 | | 1 |
| 002 | Panel Front Inner | 90191838 | 047-965-000 | 1 | 1 | 1 | 1 |
| 003 | Louvre Top | 90191840 | 147-045-000 | 1 | 1 | 1 | 1 |
| 004 | Panel Air Filter | 90194434 | 017-0091000 | 1 | 1 | 1 | 1 |
| 005 | Retainer Glass Outer | 90197125 | 047-966-000 | 2 | 2 | 2 | 2 |
| 006 | Bracket Reflector Side | 90197117 | 047-967-000 | 2 | 2 | 2 | 2 |
| 007 | Glass Front | 90193041 | 051-107-000 | 1 | 1 | 1 | 1 |
| 008 | Seal Glass Front | 90194180 | 580-0471000 | 2 | 2 | 2 | 2 |
| 009 | Seal Glass Top | 90194281 | 580-0472000 | 2 | 2 | 2 | 2 |
| 010 | Glass Fixed Supporting Flame | | 047-968-000 | 4 | 4 | 4 | 4 |
| 011 | Reflector RH | 90196034 | 038-184-R00 | 1 | 1 | 1 | 1 |
| 012 | Reflector LH | 90196036 | 038-184-L00 | 1 | 1 | 1 | 1 |
| 013 | Reflector Bottom | 90196038 | 038-185-000 | 1 | 1 | 1 | 1 |
| 014 | Reflector Top | 90196040 | 038-186-000 | 1 | 1 | 1 | 1 |
| 015 | Panel Mesh | 90194040 | 022-004-000 | 1 | 1 | 1 | 1 |
| 016 | Retainer Mesh Top Bottom | 90197228 | 538-0462000 | 2 | 2 | 2 | 2 |
| 017 | Retainer Mesh Side | 90197230 | 538-0463000 | 2 | 2 | 2 | 2 |
| 018 | Light Shield | 90197232 | 515-309-000 | 1 | 1 | 1 | 1 |
| 019 | Panel Kick | 90199888 | 019-3698000 | 1 | | 1 | |
| 019 | Panel Kick | 90199890 | 019-3699000 | | 1 | | 1 |
| 020 | Louvre Bottom | 90198009 | 095-235-000 | 1 | 1 | 1 | 1 |
| 021 | Seal V | | 526-146-000 | 2 | 2 | 2 | 2 |
| 022 | Dress Guard | 90197762 | 056-197-000 | 1 | 1 | 1 | 1 |
| 023 | Panel Top | 90190378 | 001-0439000 | 1 | | | |
| 023 | Panel Top | 90190380 | 001-0440000 | | 1 | | |
| 024 | Panel Top | 90190402 | 001-0441000 | | | 1 | |
| 024 | Panel Top | 90190404 | 001-0442000 | | | | 1 |
| 025 | Panel RH | 90190910 | 003-911-000 | 1 | | | |
| 025 | Panel RH | 90190912 | 003-912-000 | | 1 | | |

REH-311FTB-1S / REH-311FTB-1A / REH-311FTC-1S / REH-311FT

| | | | | INBUILT - G.SILVER | INBUILT - BEIGE | CONSOLE - G.SILVER | CONSOLE - BEIGE |
|-----|---------------------------------|----------|-------------|--------------------|-----------------|--------------------|-----------------|
| 026 | Panel RH | 90190914 | 003-913-000 | | | 1 | |
| 026 | Panel RH | 90190916 | 003-914-000 | | | | 1 |
| 027 | Panel LH | 90190918 | 003-915-000 | 1 | | | |
| 027 | Panel LH | 90190920 | 003-916-000 | | 1 | | |
| 028 | Panel LH | 90190922 | 003-917-000 | | | 1 | |
| 028 | Panel LH | 90190924 | 003-918-000 | | | | 1 |
| 029 | Panel Control | 90199618 | 098-2085000 | 1 | | 1 | |
| 029 | Panel Control | 90199620 | 098-2086000 | | 1 | | 1 |
| 032 | Control Panel Heat Shield Assy | | 030-0215000 | 1 | 1 | 1 | 1 |
| 033 | Side Plate Support Right | | 044-163-000 | 2 | 2 | 2 | 2 |
| 034 | Side Plate Support Left | | 044-164-000 | 2 | 2 | 2 | 2 |
| 035 | Thermistor Lid | 90190493 | 061-063-000 | 2 | | 2 | |
| 035 | Thermistor Lid | 90150475 | 061-059-000 | | 2 | | 2 |
| 036 | Airtight Panel | | 525-080-000 | 1 | 1 | 1 | 1 |
| 037 | Rear Main Body Assembly | | 014-451-000 | 1 | 1 | 1 | 1 |
| 038 | Main Body Upper Panel | | 001-0443000 | 1 | 1 | 2 | 2 |
| 039 | Convection Guide | | 515-310-000 | 1 | 1 | 1 | 1 |
| 040 | Inside Main Body Upper | | 001-0444000 | 1 | 1 | 1 | 1 |
| 041 | Gasket A | | 580-809-000 | 2 | 2 | 2 | 2 |
| 042 | Cord Cover | | 098-2087000 | 1 | 1 | 1 | 1 |
| 043 | Inside Main Body R A | | 014-452-000 | 1 | 1 | 1 | 1 |
| 044 | Inside Main Body L A | | 014-453-000 | 1 | 1 | 1 | 1 |
| 045 | Combustion Chamber Seal Plate R | | 525-081-000 | 1 | 1 | 1 | 1 |
| 046 | Combustion Chamber Seal Plate L | | 525-082-000 | 1 | 1 | 1 | 1 |
| 047 | Air Guide Plate | | 515-311-000 | 1 | 1 | 1 | 1 |
| 048 | B Main Body Base R | | 112-078-000 | 1 | 1 | | |
| 049 | B Main Body Base L | | 112-079-000 | 1 | 1 | | |
| 050 | C Main Body Base R | | 112-080-000 | | | 1 | 1 |
| 051 | C Main Body Base L | | 112-081-000 | | | 1 | 1 |
| 052 | Main Body Side Panel C | | 003-919-000 | | | 2 | 2 |
| 053 | Main Body Support | | 538-0464000 | 2 | 2 | | |

| REH-311FTB-1S / REH-311FTB-1A / REH-311FTC-1S / REH-311FT | | | | INBUILT - G.SILVER | INBUILT - BEIGE | CONSOLE - G.SILVER | CONSOLE - BEIGE |
|---|-----------------------------|----------|-------------|--------------------|-----------------|--------------------|-----------------|
| 054 | Motor Cover | | 098-0033000 | 1 | 1 | 1 | 1 |
| 055 | Spigot Flue | 90175761 | 055-556-000 | 1 | 1 | 1 | 1 |
| 056 | Wall Spacer | 90147471 | 504-018-000 | | | 1 | 1 |
| 057 | Spacer Top | 90190436 | 550-222-000 | | | 1 | |
| 057 | Spacer Top | 90190438 | 550-223-000 | | | | 1 |
| 058 | Spacer Side | 90190440 | 550-224-000 | | | 2 | |
| 058 | Spacer Side | 90190442 | 550-225-000 | | | | 2 |
| 100 | Radiant | 90142282 | ----- | 6 | 6 | 6 | 6 |
| 101 | Heat Exchanger | 90192568 | 314-436-000 | 1 | 1 | 1 | 1 |
| 102 | Heat Exchanger Support | | 538-0465000 | 2 | 2 | 2 | 2 |
| 103 | Cooling Plate | | 525-083-000 | 1 | 1 | 1 | 1 |
| 104 | Rod Holding Radiant | 90147091 | 538-228-000 | 1 | 1 | 1 | 1 |
| 105 | Supporting Pole Fixed Plate | | 537-0678000 | 1 | 1 | 1 | 1 |
| 106 | Snap Pin | | 505-011-000 | 1 | 1 | 1 | 1 |
| 107 | Combustion Chamber | 90150905 | 092-059-000 | 1 | 1 | 1 | 1 |
| 108 | Packing Glass Panel | 90147133 | 580-655-000 | 1 | 1 | 1 | 1 |
| 109 | Clip | | 504-081-010 | 8 | 8 | 8 | 8 |
| 110 | Panel Glass | 90147109 | 051-081-000 | 1 | 1 | 1 | 1 |
| 112 | Retainer Inner Rear | 90197227 | 538-0466000 | 2 | 2 | 2 | 2 |
| 113 | Retainer Inner Side | 90147125 | 538-084-000 | 2 | 2 | 2 | 2 |
| 114 | Burner Box | 90149097 | 527-204-000 | 1 | 1 | 1 | 1 |
| 115 | Box Front Panel Assembly | | 019-0707000 | 1 | 1 | 1 | 1 |
| 116 | Gasket D | | 510-0029000 | 1 | 1 | 1 | 1 |
| 117 | Filter Burner | 90148982 | 017-972-000 | 1 | 1 | 1 | 1 |
| 118 | Burner Assembly | 90148990 | 150-487-000 | 1 | 1 | 1 | 1 |
| 119 | Damper | 90199146 | 140-784-000 | 1 | 1 | 1 | 1 |
| 120 | Flame Rod | 90150483 | 230-054-000 | 1 | 1 | 1 | 1 |
| 121 | Flame Rod Retainer | | 538-232-000 | 1 | 1 | 1 | 1 |
| 122 | Electrode | 90150509 | 202-087-000 | 1 | 1 | 1 | 1 |
| 123 | Electrode Retainer | | 538-233-000 | 1 | 1 | 1 | 1 |
| 124 | Gas Control Bracket | | 537-0679000 | 1 | 1 | 1 | 1 |

REH-311FTB-1S / REH-311FTB-1A / REH-311FTC-1S / REH-311FT


| | | | | INBUILT - G.SILVER | INBUILT - BEIGE | CONSOLE - G.SILVER | CONSOLE - BEIGE |
|-----|-------------------------------|----------|-------------|--------------------|-----------------|--------------------|-----------------|
| 125 | Injector Main LP | 90190238 | 130-218-160 | 1 | 1 | 1 | 1 |
| 125 | Injector Main NG | 90190240 | 130-218-250 | 1 | 1 | 1 | 1 |
| 126 | Gas Control LP / NG | 94298115 | 114-494-000 | 1 | 1 | 1 | 1 |
| 127 | Inlet Frange | | 190-194-000 | 1 | 1 | 1 | 1 |
| 128 | Pressure Point | | 501-193-000 | 2 | 2 | 2 | 2 |
| 129 | Gasket | 90176637 | 510-519-000 | 1 | 1 | 1 | 1 |
| 130 | Filter Gas | 90182692 | 017-287-000 | 1 | 1 | 1 | 1 |
| 131 | Inlet Pipe | | 106-662-000 | 1 | 1 | 1 | 1 |
| 132 | Gas Supply Tube Fixed Bracket | | 037-0036000 | 2 | 2 | 2 | 2 |
| 133 | Gas Supply Tube Elbow | | 191-317-000 | 1 | 1 | 1 | 1 |
| 134 | O-Ring Gas | 90195167 | 520-353-000 | 5 | 5 | 5 | 5 |
| 135 | Outlet Elbow | | 191-318-000 | 1 | 1 | 1 | 1 |
| 136 | Outlet Pipe | | 106-663-000 | 1 | 1 | 1 | 1 |
| 137 | Nozzel Holder | | 537-0680000 | 1 | 1 | 1 | 1 |
| 138 | Screw Test Point | 92099956 | 501-275-005 | 2 | 2 | 2 | 2 |
| 139 | O-Ring (S4) | 90195165 | 520-300-010 | 2 | 2 | 2 | 2 |
| 140 | Gas Supply Tube Bracket | | 537-0681000 | 1 | 1 | 1 | 1 |
| 141 | Inlet Elbow assy | 90199622 | 191-319-000 | 1 | 1 | 1 | 1 |
| 142 | Circuit Board Spacer | | 550-226-000 | 4 | 4 | 4 | 4 |
| 143 | Combustion Fan Casing Assy | | 098-2088000 | 1 | 1 | 1 | 1 |
| 144 | Seal Top Fan Comb | 90157983 | 580-008-000 | 1 | 1 | 1 | 1 |
| 145 | Fan Comb Assy | 90196811 | 222-605-000 | 1 | 1 | 1 | 1 |
| 146 | Seal Bottom Comb Fan | 90157991 | 580-007-000 | 1 | 1 | 1 | 1 |
| 147 | Combustion Fan Motor Bracket | | 537-0682000 | 1 | 1 | 1 | 1 |
| 148 | S Tight Screw | | 501-303-000 | 4 | 4 | 4 | 4 |
| 149 | Cushion | 90183195 | 540-051-000 | 4 | 4 | 4 | 4 |
| 150 | Fan | | 040-279-000 | 1 | 1 | 1 | 1 |
| 151 | Combustion Fan Motor Bracket | | 537-0683000 | 1 | 1 | 1 | 1 |
| 152 | Combustion Fan | | 040-280-000 | 1 | 1 | 1 | 1 |
| 153 | Pipe Retainer | | 538-235-000 | 1 | 1 | 1 | 1 |
| 154 | Exhaust Exit Pipe | | 554-177-000 | 1 | 1 | 1 | 1 |

REH-311FTB-1S / REH-311FTB-1A / REH-311FTC-1S / REH-311FT


| | | | | INBUILT - G.SILVER | INBUILT - BEIGE | CONSOLE - G.SILVER | CONSOLE - BEIGE |
|-----|--------------------------------------|----------|-------------|--------------------|-----------------|--------------------|-----------------|
| 155 | Convection Fan Assembly | 90190640 | 040-360-000 | 1 | 1 | 1 | 1 |
| 156 | Convection Fan Casing Assembly | | 098-0169000 | 1 | 1 | 1 | 1 |
| 157 | Fan Conv | 90150657 | 040-267-000 | 1 | 1 | 1 | 1 |
| 158 | Housing with L/S Bearing | 90141540 | 067-014-000 | 1 | 1 | 1 | 1 |
| 159 | LS Bearing | | 067-013-000 | 1 | 1 | 1 | 1 |
| 160 | Convection Fan Casing Bracket | | 537-0687000 | 1 | 1 | 1 | 1 |
| 161 | L/H Conv. Fan Motor Heat Shield | | 030-0216000 | 1 | 1 | 1 | 1 |
| 162 | Top Plate Support | | 508-0038000 | 1 | 1 | 1 | 1 |
| 163 | Protector | | 525-084-000 | 1 | 1 | 1 | 1 |
| 164 | PCB Heat Shield Plate | | 030-0217000 | 1 | 1 | 1 | 1 |
| 700 | PCB Control | 90191255 | 200-0509000 | 1 | 1 | 1 | 1 |
| 701 | PCB Main | 90190253 | 200-0510000 | 1 | 1 | 1 | 1 |
| 702 | Igniter | 90193060 | 211-206-000 | 1 | 1 | 1 | 1 |
| 703 | Combustion Fan Assy | 90196811 | 222-606-000 | 1 | 1 | 1 | 1 |
| 704 | Lead Earth | | 231-031-000 | 1 | 1 | 1 | 1 |
| 705 | Fan Conv | 90190667 | 222-607-000 | 1 | 1 | 1 | 1 |
| 706 | Resistor Ceramic | 90197961 | 237-081-000 | 1 | 1 | 1 | 1 |
| 707 | Fan Comb | 90190769 | 290-1475000 | 1 | 1 | 1 | 1 |
| 708 | Harness Ignitor | 90190773 | 290-1476000 | 1 | 1 | 1 | 1 |
| 709 | Harness Fan Conv | 90190771 | 290-1477000 | 1 | 1 | 1 | 1 |
| 710 | Thermal Fuse includes Flame Rod Lead | 90190717 | 290-1478000 | 1 | 1 | 1 | 1 |
| 711 | Thermistor Assy | 90190495 | 233-267-000 | 1 | 1 | 1 | 1 |
| 712 | Earth Harness | | 290-1479000 | 1 | 1 | 1 | 1 |
| 713 | Lead HT | 90198289 | 203-867-000 | 1 | 1 | 1 | 1 |
| 714 | Electrical Cord | 90182916 | 206-180-000 | 1 | 1 | 1 | 1 |

19. Exploded Diagrams

REH-311FTB
REH-311FTC



REH-311FTB
REH-311FTC




REH-311FTC


This exploded view diagram illustrates the assembly of the REH-311FTC refrigerator. The components are numbered as follows:

- 100:** Refrigerator door
- 101:** Door hinge
- 102:** Door seal
- 103:** Door latch
- 104:** Door frame
- 105:** Door panel
- 106:** Door handle
- 107:** Door trim
- 108:** Door gasket
- 109:** Door hinge pin
- 110:** Door hinge bracket
- 111:** Door hinge pin
- 112:** Door hinge pin
- 113:** Door hinge pin
- 114:** Door hinge pin
- 115:** Door hinge pin
- 116:** Door hinge pin
- 117:** Door hinge pin
- 118:** Door hinge pin
- 119:** Door hinge pin
- 120:** Door hinge pin
- 121:** Door hinge pin
- 122:** Door hinge pin
- 123:** Door hinge pin
- 124:** Door hinge pin
- 125:** Door hinge pin
- 126:** Door hinge pin
- 127:** Door hinge pin
- 128:** Door hinge pin
- 129:** Door hinge pin
- 130:** Door hinge pin
- 131:** Door hinge pin
- 132:** Door hinge pin
- 133:** Door hinge pin
- 134:** Door hinge pin
- 135:** Door hinge pin
- 136:** Door hinge pin
- 137:** Door hinge pin
- 138:** Door hinge pin
- 139:** Door hinge pin
- 140:** Door hinge pin
- 141:** Door hinge pin
- 142:** Door hinge pin
- 143:** Door hinge pin
- 144:** Door hinge pin
- 145:** Door hinge pin
- 146:** Door hinge pin
- 147:** Door hinge pin
- 148:** Door hinge pin
- 149:** Door hinge pin
- 150:** Door hinge pin
- 151:** Door hinge pin
- 152:** Door hinge pin
- 153:** Door hinge pin
- 154:** Door hinge pin
- 155:** Door hinge pin
- 156:** Door hinge pin
- 157:** Door hinge pin
- 158:** Door hinge pin
- 159:** Door hinge pin
- 160:** Door hinge pin
- 161:** Door hinge pin
- 162:** Door hinge pin
- 163:** Door hinge pin
- 164:** Door hinge pin
- 165:** Door hinge pin
- 166:** Door hinge pin
- 167:** Door hinge pin
- 168:** Door hinge pin
- 169:** Door hinge pin
- 170:** Door hinge pin
- 171:** Door hinge pin
- 172:** Door hinge pin
- 173:** Door hinge pin
- 174:** Door hinge pin
- 175:** Door hinge pin
- 176:** Door hinge pin
- 177:** Door hinge pin
- 178:** Door hinge pin
- 179:** Door hinge pin
- 180:** Door hinge pin
- 181:** Door hinge pin
- 182:** Door hinge pin
- 183:** Door hinge pin
- 184:** Door hinge pin
- 185:** Door hinge pin
- 186:** Door hinge pin
- 187:** Door hinge pin
- 188:** Door hinge pin
- 189:** Door hinge pin
- 190:** Door hinge pin
- 191:** Door hinge pin
- 192:** Door hinge pin
- 193:** Door hinge pin
- 194:** Door hinge pin
- 195:** Door hinge pin
- 196:** Door hinge pin
- 197:** Door hinge pin
- 198:** Door hinge pin
- 199:** Door hinge pin
- 200:** Door hinge pin

REH-311FTB
REH-311FTC



REH-311FTB
REH-311FTC



SERVICE CONTACT POINTS

Rinnai

Rinnai Australia Pty. Ltd. ABN 74 005 138 769

Head Office

10-11 Walker Street,
Braeside, Victoria 3195
P.O. Box 460
Tel: (03) 9271 6625
Fax: (03) 9271 6622

Rinnai has a Service and Spare Parts network with personnel who are fully trained and equipped to give the best service on your Rinnai appliance. If your appliance requires service, please call our Help Line. Rinnai recommends that this appliance be serviced every 2 years.

Internet: www.rinnai.com.au E-mail: enquiry@rinnai.com.au

National Help Lines

Sales & Service
Tel: 1300 555 545* Fax: 1300 555 655*

**Cost of a local call Higher from mobile or public phones.*