

Rinnai

RCE-329H

SPARE PARTS MANUAL



Effective: 8/7/04
Supercedes: 2003

RCE-329H-3


No.	Part Name	RA Part No.	11 Digit Code	RJ Drawing No.	Qty
001	PANEL, Front - White	90182726	019-685-000	RC-328-60-10	1
001	PANEL, Front - Platinum Silver	90190018	019-2780000	RC-328-60-14	1
002	LOUVRE, Bottom - White	90182734	095-135-000	RC-328-36-3-SP	1
002	LOUVRE, Bottom - Platinum Silver	90190026	095-181-000	RC-328-36-5	1
003	PANEL, Rear - E		004-528-000	RC-328-42-5X02	1
003	PANEL, Rear - H		004-789-000	RC-328-42-8-SP	1
004	HOLDER, Cord	90130022	098-079-000	RC-334-73-1	1
005	PANEL, Top - White	90182742	001-557-000	RC-329-1016-3-SP	1
005	PANEL, Top - Platinum Silver		001-0230000	RC-329-1016-3-SP	1
006	PCB, Control	90182759	200-669-000	RC-329-1018X01	1
007	PANEL, Top Handle		098-391-000	RC-241-87X02	1
008	HANDLE, Packing		580-587-000	RC-241-91	1
009	PANEL, Kick - White	90182908	015-161-000	RC-328-41-5X02	1
009	PANEL, Kick - Platinum Silver		015-245-000	RC-328-41-7X01	1
010	CLIP, Saddle	90142399	523-006-000	CP-90429	1
011	FILTER, Air	90182767	017-240-000	RC-328-29X03	2
012	SCREW	90182643	501-283-000	RC-224-35-2	1
013	CLIP, Hose	90176249	504-014-000	REH211-20X02	1
014	HOLDER, Power cord		504-015-000	RC-329-1023	2
100	COVER, Secondary Air		098-392-000	RC-329-1050X01	1
101	BURNER, Assy	90182650	170-629-000	RC-329-1054	1
102	CONTROL, Gas	90182676	114-342-000	C36N-3-3X02	1
103	O Ring	90148594	520-001-010	M10B-1-8	1
104	TUBE, Gas	90182684	109-029-000	RC-329-225X02	1
105	TUBE, Connection - Clip B		537-481-000	RC-152-220X03	1
106	INJECTOR Main	90182866	130-391-170	RC-511-143-1.70	1
107	RESTRICTOR	90176504	142-074-190	RC-208-23X02-19	1
108	O Ring (S4) Test Point	90195165	520-300-010	M10B-13-4	1
109	PRESSURE, Test Point Screw	90195157	501-275-000	C10D-5	1
110	PACKING	90176637	510-519-000	C311-7X01	1
111	FILTER, Gas	90182692	017-287-000	RCK-6808N	1
112	INLET, Gas Flange	90161662	190-108-TKG	RC-204-6X03	1
113	PLATE, Burner Box		035-925-000	RC-351-35X01	1
114	ELECTRODE	90183328	202-162-000	RC-328-32-2	1
115	ELECTRODE, Bracket	90183336	506-151-000	RC-512-51	1
116	ELECTRODE, Sleeve	90195645	513-860-000	RC-223-84-BX03	1
117	CHAMBER, Combustion Hood		053-178-000	RC-209-31-9X02	1

No.	Part Name	RA Part No.	11 Digit Code	RJ Drawing No.	Qty
118	CHAMBER, Combustion Hood Cover		035-864-000	RC-209-18X08	1
119	SHIELD, Heat		030-501-000	RC-209-19X05	1
120	PANEL C, Divider		534-043-000	RC-209-36-3X02	1
121	CHAMBER, Combustion Assy		092-036-000	RC-351-11-2X03	1
123	THERMOCOUPLE, Fixing Bracket		537-648-000	RC-351-85	1
124	THERMOCOUPLE, Assy	90182817	121-334-000	RC-511-166	1
125	THERMOCOUPLE, Clip		538-041-000	RC-210-89-2	1
126	BLADE, Convection Fan	90182825	040-220-000	RC-329-18-2	1
127	HOUSING Metal		067-070-000	RC-351-69	1
128	Metal Housing - Titanium		067-031-000	RC-208-16	1
128	FAN, BRG	90156704	067-019-000	RC-233-74	1
129	CASING, Convection Fan		098-393-000	RC-328-14-1X02	1
130	BRACKET, Motor		112-025-000	RC-329-19X02	1
131	CLIP, Wire		504-017-000	CP-90312	1
132	RIVET, Nylon		523-005-000	RC-215-24-2	1
132	RIVET, Nylon		523-004-000	RC-215-24-1	1
133	Top Plate Holder		538-182-000	RC-328-55	1
134	Sparker Fixing Bracket		537-761-000	RC-329-1022	1
135	Electrical Cord Fixing Plate	90177114	538-180-000	RC-329-1033X01	1
136	BUSH Gas Inlet		194-097-000	CP-30154X01	1
137	PLATE, Top Support		538-182-000	C10D-4X01	1
139	CIRCUIT BOARD, Spacer		550-129-000	550-129-000	1
134	BRACKET, Sparker		537-761-000	RC-329-1022	1
135	BRACKET, Electric Cord	90177114	538-180-000	RC-329-1033X01	1
136	BUSHING, Piping		194-097-000	CP-30154	1
137	Pressure Test Point		501-193-000	C10D-4X01	1
139	SPACER, Circuit Board		550-129-000	CP-90436-3	4
140	FAN, Convection	90182973	040-202-000	RC-329-216X03	1
141	OHS	90183302	234-485-000	ES-01178	1
702	FUSE, Thermal	90182809	290-666-000	RC-152-269	1
703	CORD, Power Assy	90182916	206-180-000	CP-90465-2X02	1
704	FAN Motor Convection	90182833	222-378-000	RC-329-227	1
705	THERMISTOR Assy	90182841	233-133-000	RC-511-65	1
706	LEAD, TC check		209-402-000	RC-241-45-3	1
707	HARNESS, MVIG	90196700	290-590-000	RC-511-168	1
708	SPARKER Assy	90185356	211-105-000	RC-329-203-1	1
709	TRANSFORMER Main	90182791	224-223-000	ET-236-1	1
710	HARNESS, Earth	90196718	290-589-000	RC-329-235	1


Effective: 9/01/2006
 Supersedes: 1999

No.	Part Name	RA Part No.	11 Digit Code	RJ Drawing No.	Qty
711	PCB Sub	90150426	200-671-000	ED-292-1	1
712	PCB Main Unit	90182783	200-670-000	RC-329-1012-2	1
800	Wiring Diagram			RC-329-1063	1
801	Data Plate for Export			CP-72481-25	1
802	Data Plate for Export			CP-71902-20	1
802	STICKER, Gas			CP-71201	1
803	LABEL, Energy		602-192-000	CP-72335-1	1
804	LABEL, Heat Warning		602-193-000	CP-72270	1
806	LABEL, Warning	90176017	602-236-000	CP-72269-2	1
806				CP-71509	1
807	INSTRUCTIONS, Operating & Installation			RC-329-1062	1
	BRACKET, Transformer			RC-329-615	1


RCE-329H



RCE-329H



RCE-329H



RCE-329H

