


RHFE-556FDT

No.	Part Name	RA Part No	11 Digit No.
2	TOP PLATE REINFORCE		044-009-000
3	PANEL TOP 0 431 556	90102070	001-592-000
13	CONVECTION FAN BRACKET		538-060-000
22	COVER D ASSEMBLY		098-467-000
26	SPACER SIDE LOC 431 556	90102617	034-603-000
38	PANEL KICK OC 431 556	90102666	098-484-000
103	OVERHEAT SWITCH FIXING PL		537-404-000
107	SEAL PLATE ASSEMBLY		526-113-000
114	BURNER BOX GASKET RHF556	90175662	580-641-000
121	INJ MANIFOLD GASKET 556	90175688	580-335-000
125	MAGNET VALVE ASSEMBLY		114-358-000
126	PRESSURE POINT SCREW	90195157	501-275-005
127	O-RING (S-4)	90195165	520-300-010
129	O-RING (P-14)		520-024-010
132	PACKING 151 252 506 516	90176637	510-519-000
134	GAS INLET		106-301-000
137	AIR INTAKE PACKING		510-506-000
140	AIR INTAKE HOSE (L=500)		513-206-000
142	COMB CHAMB CONN TUBE	90175720	322-141-000
143	CONNECTING TUBE RETAINER		538-062-000
147	CAP		035-0078000
148	LID GASKET		580-839-000
150	S SCREW (MOTOR)		501-303-000
151	CUSHION RUBBER RCE 560PTR	90183195	540-051-000
152	EXHAUST TELESCOPIC PIPE		554-080-000
153	O RING (E)		520-160-000
154	O RING 34MM FLUE EXTENS	90122920	520-142-005
156	COVER		034-457-000
157	RING		552-075-000
158	STANDARD WALL TOP		055-553-000
160	HOSE CLIP RHF556	90170341	538-065-000
161	FAN COMBUSTION	90175738	040-214-000
162	FLUE LOCK CLAMP	90165358	512-327-000
163	TELESCOPIC PIPE STOPPER		512-326-000
398	CONVECTION FAN (R-A)		040-219-000
399	CONDENSER		225-111-000
400	CONVECTION FAN MOTOR		222-294-000
402	FAN CONVECTION	90175746	040-173-000
404	METAL		067-031-000
406	HUMIDIFIER PAN		078-016-000
408	OVERHEAT SWITCH BRACKET		537-682-000
414	ELECTRONICS UNIT BRACKET		537-689-000
416	CABLE CLIP (0248)		504-024-000
419	SPEED CLAMP		514-019-000
699	PCB MAIN 556FDT	90186065	200-889-000
701	THERMISTOR ASSY RHF556	90175787	233-117-000
703	POWER CODE ASSEMBLY		206-180-000
703	POWER CORD ASSY 329H	90182916	206-180-000
704	TRANSFORMER RHF556	90117011	224-257-000
705	MV HARNESS		204-945-000
706	HARNESS THERMAL ASSEMBLY	90193855	290-747-000
708	HIGH TENSION CORD		203-798-000
709	OVER HEAT SWITCH		234-509-000
710	OHS 130C RHF431 556	90178567	234-505-000
711	OHS 90C RHF431 556 557	90178575	234-506-000
712	SPARKER UNIT RHF556 557	90175829	262-028-000
713	ELECTRODE SLEEVE		513-109-000


RHFE-556FDT

No.	Part Name	RA Part No	11 Digit No.
714	COVER THERMAL FUSE	90180308	098-468-000
715	FLAME ROD LEAD		209-326-000
716	MOTOR HARNESS A		290-069-000
717	CONVECTION FAN MOTOR		231-022-000
719	OVER HEAT SWITCH HARNESS		290-768-000
800	MAGNET		228-011-000
801	FRONT PANEL 556FDT 0C	90103391	019-954-000
802	CONTROL LID C	90180332	035-0044000
803	DOOR HINGE & CIRCLIP	90180357	512-376-000
804	KEY & LOCK	90180324	501-387-000
805	FRONT DECORATION F-2		019-0888000
808	FRONT DECORATION L C-4		019-863-000
813	LAMP ASSEMBLY	90197757	200-480-000
814	CONTROL PCB ASSY 0C	90181694	200-724-000
819	REAR PANEL C ASSEMBLY		004-520-000
823	WARNING LABEL ELECTRIC	90176017	602-236-000
824	LABEL (NG)		602-579-000
824	LPG STICKER		602-701-000
825	WARNING LABEL	90173121	602-707-000
826	SAVE-ENERGY LABEL		602-708-000
827	WARNING LABEL RHF556	90175993	602-235-000
829	PACKING ASSY FOR OUTDOOR		510-0003000
830	UPPER INDICATION LABEL		602-709-000
999	BACK COVER FIXING PLATE		537-672-000


〈RHFE-556FDT〉




〈RHFE-556FDT〉



〈RHFE-556FDT〉



〈RHFE-556FDT〉



〈RHFE-556FDT〉

