


Constellation - CON1000B / CON1000SS

No.	Part Name	RA Part No.	RNZ Part No.	Qty
1	FLEXITUBE 1000	90199647	7835	1
2	FAN CONV 1000	90193392	10100X1	1
3	PANEL FRONT		1060V	1
4	PCB CONTROL 1000	90199563	10632	1
5	BURNER MAIN 1000	90199571	10602B	1
6	PCB MAIN 1000	90199589	10630	1
7	SPARKER 1000	90199597	10601	1
8	REFLECTOR, Rear 1000	90199654	10619	1
9	OHS 440C 1000	90199662	10637	1
10	LOUVRE TOP (3) 1000	90199670	10622B	1
11	AERATION BRACKET (NG)		10647	1
12	ELECTRICAL CORD 1000	90199688	6765B	1
13	REMOTE 1000	90199696	10633	1
14	REFLECTOR SIDE (Set) 1000	90199720	10628	1
15	PANEL, Front (3) 1000	90199738	10627V	1
	HARNESS Wiring		10300	1
*	CABLE CAT 5 x 500 mm		10631	1
*	HARNESS WIRING	90195108	10640	1
*	IGNITION WIRE	90195109	10644	1
*	LEAD FLAME ROD	90195110	10645	1
*	HARNESS OHS	90195111	10654	1
31	ELECTRODE 1000	90199746	7875	2
32	ELECTRODE NUT		7876	1
33	SPACER ELECTRODE PILOT		7902	1
34	FLAME ROD FF 1000	90187790	7520	1
35	ELECTRODE NUT (ETR)		7900	1
36	INJECTOR PILOT LPG 1000	90199753	7873	1
37	GAS CONTROL LP/NG 1000	90199761	10600	1
38	INJECTOR BRAY 420 LP1000	90199779	10643	1
39	WASHER SPRING	90189333	9233	1
40	NUT HEX M4	90189341	9186	1
41	WASHER FLAT M4ZP		9231	1
42	INJECTOR PILOT NG 1000	90199787	7872	1
43	INJECTOR BRAY1150 NG 1000	90199795	10642	1
44	PILOT HEAD 1000	90199803	7871	1
45	TUBE GAS SUPPLY 1000	90199811	10615	1
46	TUBE PILOT GAS SUPPLY 1000	90199829	10639	1

* = Not marked on exploded diagram



A (1:3)

