

Rinnai

RCE-318H

SPARE PARTS MANUAL



Effective: 23/06/04
Supercedes: 2003

Effective Date: 1/07/2004


Supercedes: 2003

RCE-318H


No.	Part Name	RA Part No.	11 Digit Code	Qty
001	Panel Front	90146028	019-870-000	1
002	Louvre Bottom	90146069	095-143-000	1
003	Back Support Louvre	90146770	095-144-000	1
004	Louvre Support Bracket	90146788	095-145-000	1
005	Panel Kick		015-227-000	1
006	Panel Top	90148446	001-594-000	1
007	Control Panel Label		063-276-000	1
008	Rear Panel Beige		004-623-000	1
009	Handle Beige	90149162	072-345-000	2
010	Holder Cord	90130022	098-079-000	1
012	Filter Assy	90149725	017-209-000	1
021	Cord Holder		504-033-000	2
025	Clip Hose	90176249	504-014-000	1
031	Cord Bush	90177106	194-098-000	1
032	Electrical Cord Bracket	90177114	538-180-000	1
100	Combustion Chamber Assy		092-033-000	1
101	Burner Assy - NG	90157603	170-240-000	1
101	Burner Assy - LPG	90158387	170-266-000	1
102	Secondary Air Cover		146-058-000	1
103	Over Heat Switch	90176488	234-468-000	1
104	Burner Blanking Plate		035-877-000	1
105	Flame Rod	90162744	202-160-000	1
106	Bracket Electrode	90183336	506-156-000	1
107	Thermocouple Main	90168758	121-273-000	1
108	TC Spacer A (t1.0)	90148248	550-099-000	1
108	TC Spacer B (t2.0)	90183823	550-100-000	1
109	Thermocouple Fixing Bracket		537-274-000	1
110	Thermocouple Holder	90176439	508-652-000	1
111	Divider Panel B		534-071-000	1
112	Combustion Chamber Hood E		053-182-000	1
113	Combustion Chamber Cover		035-864-000	1
114	Heat Shield		030-501-000	1
115	Wire Clip		504-017-000	1
116	Hood Divider Panel			1
117	Electrode Sleeve		513-109-000	1
118	Convection Fan Motor Base			1
119	Convection Fan Drum		040-171-000	1
120	Convection Fan Casing Assy		098-466-000	1

No.	Part Name	RA Part No.	11 Digit Code	Qty
121	Bearing Housing		067-068-000	1
122	BRG Fan	90156704	067-019-000	1
123	Gas Inlet	90176652	190-125-000	1
124	Gas Filter		017-025-000	1
125	Packing	90176637	510-519-000	1
126	Gas Control	90162546	120-063-000	1
127	"O" Ring	90176611	520-325-000	1
128	Injector Holder		195-073-000	1
129	Injector Main - LPG 1.15	90162793	130-333-115	1
129	Injector Main - NG 1.70	90163130	130-405-170	1
130	Injector Fixing Panel		537-396-000	1
131	Test Point Screw		501-236-000	1
132	"O" Ring	90195165	520-300-010	1
133	Restrictor Panel - NG	90176504	142-074-190	1
134	Heat Shield		030-507-000	2
135	Top Panel Bracket		537-669-000	2
136	Wire Clip		512-358-000	1
137	Gas Control Fixing Panel		537-670-000	1
138	Gas Inlet Bush		194-097-000	1
139	Bayonet Hose			1
140	PCB Main	90164831	200-698-000	1
141	PCB Main	90168709	040-224-000	1
700	PCB Main	90164831	200-698-000	1
701	TC Check Lead		209-268-000	1
702	Thermistor	90176827	233-095-000	1
703	Electrical Cord	90178161	CP-90465-1	1
704	MV Harness		204-916-000	1
705	High Limit Thermistor Hi Limit	90176934	233-094-000	1
706	TF Harness		204-915-000	1
707	Fan Convection Motor	90179029	222-287-000	1
708	PCB Sub	90150426	200-671-000	4
709	Circuit Board Spacer		550-129-000	1
710	Sparker PCB Fixing Bracket		537-671-000	1
711	Transformer	90188723	224-305-000	1
890	Wiring Diagram & Pressure Setting Label		601-013-000	1
	Operating and Installation Instructions			1

RCE-318H



RCE-318H



RCE-318H

