

REU-VR2024WB-50AK

No.	Part Name	Part No.	11 Digit Code
1	Panel Front (DOES NOT include screws)	92099996	019-4517000
2	Front Panel Packing		580-0039000
5	OUTER CASE	92092049	014-445-000
10	BRACKET WALL	92093377	106-329-000
11	Seal Packing(Gray)		510-893-000
12	Rubber Bushing		194-140-000
13	QUICK CONTROL CONNECTION	92099955	106-651-000
14	SEAL PANEL EASY CONNECT	92099984	580-0105000
15	Connection Reinforcement		044-156-000
100	INLET GAS 3/4	92081587	106-290-000
101	PRESSURE POINT SCREW	92099956	501-275-005
102	GAS CONTROL	92099198	120-0028000
103	MANIFOLD LP	92099260	101-751-000
103	MANIFOLD NG	92099262	101-752-000
104	MANIFOLD PACKING UPPER	92099286	580-0108000
105	MANIFOLD PACKING LOWER	92099290	580-0574000
106	BURNER CASE FRONT PANEL-2		098-0625000
107	PACKING		580-590-000
108	DAMPER		140-723-000
109	Lean And Rich Burner		157-083-000
110	BURNER CASE REAR PANEL		098-403-000
111	COMB.CHMB FRONT PANEL-20		019-4084000
112	COMB.CHMB FRONT PANEL PAC		580-0575000
113	ELECTRODE	92086974	202-156-000
114	ELECTRODE FR	92095598	202-215-000
115	PACKING ELECTRODE	92099214	580-0569000
116	ELECTRODE HOLDER	92099216	538-0572000
117	SLEEVE ELECTRODE	92087030	518-035-000
119	BURNER ASSY	92099268	157-138-000
120	HEAT EXCH	92099278	314-757-000
121	BRACKET	92093315	538-615-000
122	BRKET H/EXCH OUTLET	92099548	537-502-000
130	FLUE OUTLET	92099967	055-788-000
131	FLUE OUTLET PACKING		580-592-000
132	FRONT PANEL SEALING PACKI		580-600-000
150	Comb. Fan Motor	92099222	222-595-000
151	Fan Casing Assembly		035-870-000
152	FAN COMB ASSY	92099222	222-642-000
400	INLET WATER 3/4	92095901	333-483-000
401	Plug Band		553-119-000
402	FILTER WATER O LARGE	92083773	196-062-000
404	RECTIFIER WATER	92093552	330-107-000
405	WATER FLOW SERVO&SENSOR	92099957	301-152-000
406	Water Flow Servo Cover		098-1445000
408	3/4 HOT WATER CONNECTOR	92099970	333-304-000
409	Water Plug Band		553-043-000
410	VALVE PRESS RELIEF	92099944	337-152-000
700	PCB MAIN	92099226	210-951-000

701	EC Cover-2-A		098-1853000
702	Electric Unit Cover		098-0627000
703	IGNITOR ASSEMBLY	92095026	261-157-000
704	LEAD HT	92099228	203-877-000
705	IGNITOR FIXING PLATE		537-0619000
706	SURGE ARRESTOR	92093699	210-605-000
707	Sub Circuit Board Cover		098-1855000
708	Fixing Plate		537-0618000
709	ELEC CORD	92089051	206-226-000
710	FUSE HARNESS -2	92099959	290-1284000
710	HARNESS FUSE ONLY		
711	VALVE HEATER ASSEMBLY	92098318	213-001-000
712	SWICH THERMAL	92097187	234-444-000
713	HEATER FIXING PIATE	92096225	537-0440000
715	ELECTRIC POWER HARNESS	92095027	290-1285000
716	HARNESS SOLENOID	92099230	290-1746000
717	HARNESS SENSOR	92099232	290-1747000
718	THERMAL FUSE ASSEMBLY-20	92099621	290-0492000
719	Thermal Fuse Fixing Plate		537-505-000
720	Thermal Fuse Fixing Plate		537-0110000
721	SENSOR MR	92099988	243-133-000
722	HARNESS TWIN THERMIST	92099234	233-278-000
725	HARNESS REMOTE CONTROLLER	92099961	290-1288000
728	HARNESS RELAY	92099236	290-1748000
800	Earth Screw		501-889-000
801	Truss Screw		501-973-010
802	Screw		501-0064000
803	Tapping Screw		501-737-000
804	Thermistor Fixing Screw		501-295-000
820	O-RING (S-4)	90195165	520-300-010
821	O-RING GAS CON	92072859	520-043-010
822	O-RING GAS CONTROL	92096502	580-180-000
825	O-RING THERMISTOR	92062249	520-209-010
826	O-RING	92062348	520-281-010
827	HEAT EX O RING INF16	92072800	520-255-010
828	O-RING HEAT EXCHANGER	92062207	520-193-010
829	O-RING	92062199	520-048-010
830	O-RING IN/OUT WATER	92071182	520-049-010
888	Operation Manual(RAU)		623-405-400
889	Instruction Manual		K23-405-400